

Disabled Platform Lift - GAF Centre

Operating Instructions

- Remove cover and undue the Velcro straps at the bottom and lift off cover.
- Insert key in either top or bottom keypad and turn key to the **ON** position.
- Press bottom right-hand key to open lift platform - hold key down until lift has completed its cycle.
- Press and hold **UP** button on keypad until lift has arrived at top station and lift has completed its cycle.
- Load wheelchair and passenger onto the lift platform and apply brakes on the wheelchair.
- Ensure that the passenger is centrally located on the lift to ensure that when the safety bars drop into position they do not strike the head or shoulders of the passenger. Advise the passenger of the importance of this procedure.
- Press and hold **DOWN** key on keypad until lift has arrived at the bottom station and the lift cycle has been completed.
- Release brakes on wheelchair and assist passenger to exit the lift platform.
- Reverse procedure to return passenger to top station.
- After use return lift to bottom station to charge batteries. On arrival press and hold the top right-hand key to close the platform and replace the cover and Velcro straps.
- Turn key to **OFF** position and the return key to the kitchen hook for future use.

IMPORTANT

DO NOT SWITCH OFF THE MAIN POWER SWITCH IN THE COURTYARD (LARGE RED SWITCH TO THE LEFT-HAND SIDE OF THE KEYPAD) AFTER USE AS THE BATTERIES NEED TO BE ON CONTINUAL CHARGE.